



\* = AWP recommends using TEK screws to attach decking to rack beams when installing decking that does not have waterfalls to prevent rack beams from spreading.

Mesh pattern, wire gauge and number of channels depends upon requirements and application.